



Disable UPnP

UPnP (Universal Plug and Play) is used to automatically forward the recorder ports in a compatible router. Although this feature can be useful by removing the need to configure the router manually, if the feature is not required it is recommended to disable UPnP.

1. Enter the Main Menu (Right Click > Main Menu)



2. Go to Network > UPnP



3. If the UPnP enable checkbox is checked, uncheck it and click Apply followed by OK